

Round cream colored Diehl time clock

For your own safety you should turn the power off to the ETS unit before opening the cover to reprogram the unit.

To program the timer follow the steps below.

1. Use a paper clip to push the reset (R) contact in on the timer. It is the small grey button located immediately below the "h" button across the bottom of the display. This clears all programs. Hold the contact down until the display blinks 0:00.
2. Slide the RUN switch to the left to the "clock face". Press the "1...7" button below the display until the arrow at the top of the display points to the correct day of the week. (1=Monday, 2=Tuesday,...7=Sunday). Press the "h" button to set the correct hour, press the "m" button to set the correct minute. A "P" will show as a PM indicator. When the correct day and time have been set slide the RUN switch to "RUN" (center position). The colon between the hour and minute display should blink.
3. Slide the "RUN" switch to the right to "P" for program.
4. The display should show a "1" on the right side, indicating the first program cycle. A "light bulb" should be showing on the left side of the display. The time will show 12:00
5. Press the "m" button once to make the time display show 12:01 (the number 1 and the light bulb should be showing to the right of the time display).
6. Press the "1-7" button 11 times until an arrow is displayed under each of the numbers at the top of the display.
7. Press the "P" button on the left side of the display. A "2" should show on the right side of the display. The "light bulb" should not be showing. The time will show 12:00.
8. Press the "h" button until the time display shows 6:00 AM
9. Press the "1...7" button until an arrow is displayed under each of the numbers at the top of the display.
10. Press the "P" button on the left side of the display. A "3" should show on the right side of the display. The "light bulb" should be showing.
11. Press the "h" button then the "m" button (or hold down) until the time display shows 9:00 AM
12. Press the "1...7" button until an arrow is displayed under each of the numbers at the top of the display.
13. Press the "P" button on the left side of the display. A "4" should show on the right side of the display. The "light bulb" should not be showing.
14. Press the "h" button until the time display shows 5:00 PM
15. Press the "1...7" button until an arrow is displayed under each of the numbers at the top of the display.
16. Press the "P" button on the left side of the display. A "5" should show on the right side of the display. The "light bulb" should be showing.
17. Press the "h" button until the time display shows 10:00 PM
18. Press the "1...7" button until an arrow is displayed under each of the numbers at the top of the display.
19. Press the "P" button on the left side of the display. A "6" should show on the right side of the display. The "light bulb" should not be showing.
20. Press the "h" button then the "m" button (or hold down) until the time display shows 11:59 PM
21. Press the "1...7" button until an arrow is displayed under each of the numbers at the top of the display.
22. Slide the RUN switch back to "RUN"
23. Turn the power back on at the circuit breaker panel.
24. Have a beverage of your choice. YOU'RE DONE, and you've earned it.