

Three button Theben time clock.

For your own safety you should turn the power off to the ETS unit before opening the cover to reprogram the unit.

To program the timer follow the steps below.

1. Clear the existing charge (ON) and control (OFF) cycles by
 - a. Pressing "Menu" until "Prog" is flashing. Press "OK"
 - b. "NEW PROG" will flash across the top of the display. Press the < or the > button until "CLEAR" flashes on the display. Press "OK"
 - c. "SINGLE" will flash on the display. Press the < or the > button until "ALL" is flashing on the display. Press "OK" and "CONFIRM" will flash on the display.
 - d. Press "OK" to confirm clearing all program settings.
2. Press the "MENU" button until "Prog" is flashing in the upper portion of the display. Press "OK".
3. Press the < or > button until "NEW PROG" is flashing in the display. Press "OK". "FREE" and a number will appear after a few seconds to indicate how many program locations are available. There should be 28 program locations available. If not repeat step 1 above.
4. The clock will then display "TIME ON" or "TIME OFF" at the top of the display. Underneath that, "On" or "Off" will be flashing. Use the < or > button to set the display at "TIME OFF" and "Off". Press the "OK" button.
5. "HOUR" will be displayed across the top. Use the < or > button to set the hour at 6:00 AM. Press "OK".
6. "MINUTE" will be displayed across the top. Use the < or > button to set the minute at :00 if necessary. Press "OK".
7. "MONDAY" will display. Press "OK" and "COPY" will flash. Press "OK" and "ADD TU" will appear. Continue to press "OK" for all the days of the week except Sunday. After "ADD SA" is selected, "STORE" flashes on the display. Press "OK".
8. "NEW PROG" will flash on the display. Press "OK"
9. The clock will then display "TIME ON" or "TIME OFF" at the top of the display. Underneath that, "On" or "Off" will be flashing. Use the < or > button to set the display at "TIME ON" and "On". Press the "OK" button
10. "HOUR" will be displayed across the top. Use the < or > button to set the hour at 9: AM. Press "OK"
11. "MINUTE" will be displayed across the top. Use the < or > button to set the minute at :00 if necessary. Press "OK".
12. "MONDAY" will display. Press "OK" and "COPY" will flash. Press "OK" and "ADD TU" will appear. Continue to press "OK" for all the days of the week except Sunday. After "ADD SA" is selected, "STORE" flashes on the display. Press "OK".
13. "NEW PROG" will flash on the display. Press "OK"
14. The clock will then display "TIME ON" or "TIME OFF" at the top of the display. Underneath that, "On" or "Off" will be flashing. Use the < or > button to set the display at "TIME OFF" and "Off". Press the "OK" button.
15. "HOUR" will be displayed across the top. Use the < or > button to set the hour at 5: PM. Press "OK"
16. "MINUTE" will be displayed across the top. Use the < or > button to set the minute at :00 if necessary. Press "OK".

17. "MONDAY" will display. Press "OK" and "COPY" will flash. Press "OK" and "ADD TU" will appear. Continue to press "OK" for all days except Sunday. After "ADD SA" is selected, "STORE" flashes on the display. Press "OK".
18. "NEW PROG" will flash on the display. Press "OK"
19. The clock will then display "TIME ON" or "TIME OFF" at the top of the display. Underneath that, "On" or "Off" will be flashing. Use the < or > button to set the display at "TIME ON" and "On". Press the "OK" button
20. "HOUR" will be displayed across the top. Use the < or > button to set the hour at 10: PM. Press "OK"
21. "MINUTE" will be displayed across the top. Use the < or > button to set the minute at :00 if necessary. Press "OK".
22. "MONDAY" will display. Press "OK" and "COPY" will flash. Press "OK" and "ADD TU" will appear. Continue to press "OK" for all the days of the week except Sunday. After "ADD SA" is selected, "STORE" flashes on the display. Press "OK".
23. "NEW PROG" will flash on the display. Press "Menu"
24. Check the program settings.
 - a. Press "Menu" until "Prog" is flashing. Press "OK"
 - b. "NEW PROG" will flash across the display. Press < or > until "CHECK" flashes on the display.
 - c. Press "OK" to step through the program steps. If correct, press "MENU" to return to normal operation. If not, return to step 1 to clear and reprogram.
By not programming in Sunday you will have off-peak all day.
25. Turn the power back on at the circuit breaker panel.
26. Have a beverage of your choice. YOU'RE DONE, and you've earned it.